

# TECHNICAL DATA SHEET

## Walther Strong HD Plastering Scrim



Description	Product Code	Size	Unit
Heavy Duty self-adhesive fibre-glass tape	TP-ORNSCRIM50X-90PR	50mm x 90m	Roll
Heavy Duty self-adhesive fibre-glass tape	TP-ORNSCRIM75X-90PR	75mm x 90m	Roll
Heavy Duty self-adhesive fibre-glass tape	TP-ORN-SCRIM100X90PR	100mm x 90m	Roll
Heavy Duty self-adhesive fibre-glass tape	TP-XLSCRIM50X180	50mm x 180m	Roll



### Available Colours Available Widths Box Quantities

White, Orange	50mm	50mm	- 36
	75mm	75mm	- 24
Lengths 90m, 180m	100mm	100mm	- 18
	500mm	50mmx180m	- 12
		500mmx90m	- 6

### Application

Flat plasterboard joints must be reinforced with Walther Strong glass fibre mesh tape. Position the tape and spread the plaster along each joint. To minimise the risk of cracking, ensure that the plaster is pushed through the tape well into any gaps between the plasterboards. Apply plaster to the plasterboard surface and joints with firm pressure after the joint treatment has stiffened but not set. Build out to a 2mm thickness in two applications, wet-on-wet and trowel to a smooth matt finish. Sand each joint once it has dried, to achieve a smooth matt finish.

### How to Cut

Use a knife or trowel to cut to size.

### Storage

Store between 8-30°C. Do not use if left in a van overnight in cold weather. Remove, bring to room temperature (minimum 15°C) before using if cold weather. Avoid frost.

		Metric	Imperial	ATSM Method
Construction: (per 100mm)	Warp Weft	36 36	9 9	D-3775
Weight: (g/m <sup>2</sup> - oz/yd <sup>2</sup> )		63.1+/-2.2	1.85 +/- 0.1	D-3776
DPU (Coating and PSA on fabric in weight %)		40-45%	40-45%	SGTF
Thickness: (per mm - per inch)		0.3	0.01	D-1777
Tensile Strength: (N/2.54cm - lbs/in)	Warp Weft	228 470	50 105	